



Cleaning instruction for ALUCOND heat exchanger



PRODUCTS AND EQUIPMENTS TO USE:

a. Product TOPTHERM CLEAN F9A GEL



b. Product TOPTHERM CLEAN F9B



c. Nylon brush



CLEANING INSTRUCTION

During cleaning process, operator must wears gloves, mask and safety glasses.

1

Please follow below instructions to remove burner:



3

Wait 10 minutes. Product will react with Aluminum oxides and combustion products.

5

Repeat operation 2-3-4 some times, for a good result.

6

In case of residual fouling, remove them using nylon brush (picture C) and aspire.



2

Apply, some product CLEAN F9A GEL (picture A) of company TOPTHERM in order to wet all the upper surface of the heat exchanger and checking correct liquid outflow through fins pack.



4

Rinse all the heat exchanger with water, and discharging dirtiness through siphon.



7

Apply, CLEAN F9B (picture B) the product CLEAN F9B acid in order to wet all the upper surface of the heat exchanger and checking correct liquid outflow through fins pack.





MADE IN ITALY



G20 ENGINEERING SRL Loc. Campogrande 13, 29013 CARPANETO PIACENTINO (PC), Italy
tel. + 39 0523 850513 - fax. +39 0523 850712 - www.aircontrol-pc.com - www.g20engineering.com